

Specialty Manufacturing SafetyGuard Roof Hatches are designed to provide and accessible exit from the bus in the event of an accident. To make the hatch as accessible as possible, operation of the hatch has been kept simple, operating in the same manner as any conventional door. Follow the two step instructions below for operating the hatch.

- 1. Turn hatch release handle either left or right
- 2. Push (or pull if opening from outside) the hatch to a full open position

To close the hatch, simply reverse the above procedure.

For roof hatches equipped with a vent, then vent may be operated as follows:

- 1. Push vent handle (black knob) forward to open the vent toward the front of the bus
- 2. Push vent handle rearward to open the vent toward the rear of the bus.

When fully closed, the vent handle will be in a straight up and down position.

PO Box 790 10200 Pineville Rd Pineville, NC 28134 (704) 889-7518 Fax (704) 889-2760 www.specmfg.com